

Bash plate Installation Instructions

Model : Yamaha Super Tenere
Year : 2011

Part No: FA-005-YA-09

1. Remove stock plastic bashplate. Bolt front mounting brackets to the tapped lugs located on the sump, and to the upper mounting holes shown in figure 1, using supplied M8 and M10 bolts. Apply the foam strips provided to the flat bottom of the front mounting brackets.
2. Remove the left kickstand and replace the kickstand spacer with the left rear mounting bracket as shown in figure 2. The shift linkage must be disconnected to reach these bolts.
3. Remove the exhaust mounting bracket and replace with the right rear mounting bracket as shown in figure 3.
4. Support the bashplate underneath the sump and attach the front of the bashplate to the front brackets using the supplied M8 cap screws. Attach the rear of the bashplate to the rear bracket using the remaining screws. Ensure the shift linkage is reconnected.



Figure 1



Figure 2



Figure 3